



The operator inserts the plate in to the punching machine and pushes it in to the register pins stop. The correct position is displayed by the indicator lights, after start vacuum and punching.

Automatically the plate is sent into the processor or stacker.

For large plate size, rollers are replaced by belts (going up and down) to facilitate the positioning.

- Structure in modular aluminium profiles.
- Belt or roller conveyor for move plate to processor or stacker.
- Siemens Plc.
- 3 register pins stop with electric contact
- Vacuum system for plate hold
- 2 Punch device
- Sound alarm warns that there is a problem

Optical version available for greater punching accuracy